

Absolute Process Instruments, Inc.

Manufacturer of Quality Signal Conditioners Transmitters & Isolators

Application Notes

- General Info
- Temperature
- Pressure
- Flow
- Speed
- Weighing
- Process


Monitoring and Controlling Differential Temperature

PROBLEM

Monitor the temperature differential across a heat exchanger and provide an output signal for the process control computer and a local display.

SOLUTION

Install RTDs to measure the heat exchanger inlet and outlet temperatures and connect the RTDs to an **API 4001 G SA-B** Non-Isolated Differential RTD to DC Transmitter module.



The **API 4001 G SA-B** will directly measure the temperature differential and provide an output to drive the local display and the process control computer.

Did You Know...?

Api will do non-standard and special ranges on all of our products.

FREE APPLICATION ASSISTANCE

Call  Customer Service

800-942-0315

